

0579 Spice Plate
30.5cm (12")
0580 25.5cm (10")
0581 20.25cm (8")
0582 15.25cm (6")



0585 Zest Platter
30.5cm (12")
0586 25.5cm (10")
0587 20.25cm (8")



0596 Essence Bowl
20.25cm (8")
0597 16.5cm (6½")
0598 14.0cm (5½")



0574 Scoop Bowl
16.5cm (6½")
0583 11.2cm (4½")
0584 7.9cm (3½")



0577 Tasters Tray
25.5cm x 13.0cm
(10" x 5")



0576 Tasters Bowl
13.0cm x 13.0cm
(5" x 5")



B828 Casserole Base
42.5cl (15oz)
0829 Casserole Lid



0599 Tilt Pot
7.5cm (h) x 7.9cm (w)
(3½" x 3")



0575 Tasters Dip
6.5cm x 6.5cm
(2½" x 2½")



0592 Quench Mug
28.5cl (10oz)



0152 Low Cup Empire
34.0cl (12oz)
0189 22.75cl (8oz)
0190 8.5cl (3oz)



0217 Cup Stacking
Slimline
20.0cl (7oz)



0225 Saucer Double
Well Slimline
16.5cm (6½")
0158 Large
14.5cm (5¾")
0165 Small
11.5cm (4½")



0367 Club Teapot
42.5cl (15oz)



0387 Club Jug
14.25cl (5oz)




0379 Sugar/Bouillon Cup
22.75cl (8oz)



0840 Bud Vase
Harmony



0841 Salt Harmony
0842 Pepper Harmony



6506G231 Tasters Charger (Glass)
30.5cm x 30.5cm
(12" x 12")



6515T346 Tasters Charger (Dark Wood)
30.0cm x 30.0cm
(11¾" x 11¾")



6515T345 Tasters Charger (Light Wood)
30.0cm x 30.0cm
(11¾" x 11¾")